Freightliner DDEC6 Wiring

Connection using Boot Mode

Attention

You cannot use OBD Flash files to write into the ECU

Please contact Microtonik to help you in arranging the boot location of **DDEC6**