

## Audi DQ200 Gen2 Wiring

### Connection using Factory Mode

## Attention

**You cannot use OBD Flash files to write into the ECU**



Audi-DQ200 Gen2-Module

You don't need to open DQ200 Gen2 cover in this factory mode. Please connect wires as described below

# B1



## Pins Description

- Block1-**Pin 11**: Power Supply 12-14V
- Block1-**Pin 3**: Power Supply 12-14V
- Block1-**Pin 4**: Ground
- Block1-**Pin 8**: CANBUS High 2
- Block1-**Pin 9**: CANBUS Low 2