

## Volvo EDC17CP22 Wiring

### Connection using Factory Mode


## Attention

**You cannot use OBD Flash files to write into the ECU**



Volvo-EDC17CP22-Module

You don't need to open EDC17CP22 cover in this factory mode. Please connect wires as described below



### Pins Description

- Block1-**Pin 35**: Clock 1 Signal
- Block1-**Pin 7**: Clock 2 Signal
- Block2-**Pin 15**: Power Supply 12-14V
- Block2-**Pin 2**: Ground
- Block2-**Pin 41**: CANBUS Low 2
- Block2-**Pin 5**: Power Supply 12-14V
- Block2-**Pin 54**: CANBUS High 2