

Lancia ME7.9.10 Wiring

Connection using Boot Mode


Attention

You cannot use OBD Flash files to write into the ECU



Lancia-ME7.9.10-Module

You need to open ME7.9.10 cover in boot mode. Please connect wires as described below



Pins Description

- Block2-Pin 2: Ground
- Block2-Pin 6: Power Supply 12-14V
- Block2-Pin 70: Power Supply 12-14V
- Block2-Pin 91: K-Line Signal

Internal Wiring

Connect HexProg signals wires to ME7.9.10 board as shown below



Lancia-ME7.9.10-Inside



Lancia-ME7.9.10-Boot-Location