


Mitsubishi Fuso EDC17C49 Wiring

Connection using Factory Mode

Attention

You cannot use OBD Flash files to write into the ECU

You don't need to open EDC17C49 cover in this factory mode. Please connect wires as described below



Pins Description

- Block1-Pin 14: Clock 1 Signal
- Block1-Pin 59: Clock 2 Signal
- Block2-Pin 2: Ground
- Block2-Pin 24: CANBUS High 2
- Block2-Pin 25: CANBUS Low 2
- Block2-Pin 5: Power Supply 12-14V
- Block2-Pin 54: Power Supply 12-14V