Volvo ME9.0 Wiring

Connection using Factory Mode

Attention


You cannot use OBD Flash files to write into the ECU



Volvo-ME9.0-Module

You don't need to open ME9.0 cover in this factory mode. Please connect wires as described below

Option 1



Pins Description for Option 1

• Block1-Pin 47: K-Line Signal

• Block1-Pin 53: Clock 2 Signal


• Block1-Pin 59: Clock 1 Signal

• Block2-Pin 15: Power Supply 12-14V

Block2-Pin 16: Power Supply 12-14V

• Block2-Pin 4: Ground

Option 2



Pins Description for Option 2

• Block1-Pin: 53 Clock 2 Signal

• Block1-Pin: 61 Clock 1 Signal

• Block2-Pin: 2 Ground

• Block2-Pin: 30 Power Supply 12-14V

• Block2-Pin: 43 K-Line Signal

• Block2-Pin: 54 Power Supply 12-14V