


Toyota ME17.9.5 Wiring

Connection using Factory Mode

Attention

You cannot use OBD Flash files to write into the ECU

You don't need to open ME17.9.5 cover in this factory mode. Please connect wires as described below



Pins Description

- Block 1-**Pin 1**: CANBUS High 2
- Block 1-**Pin 2**: CANBUS Low 2
- Block 1-**Pin 5**: Power Supply 12-14V
- Block 1-**Pin 56**: Power Supply 12-14V
- Block 2-**Pin 50**: Ground
- Block 2-**Pin 8**: Clock 2 Signal
- Block 2-**Pin 9**: Clock 1 Signal