

Renault EDC16C41 Wiring

Connection using Factory Mode

Attention


You cannot use OBD Flash files to write into the ECU

You don't need to open EDC16C41 cover in this factory mode. Please connect wires as described below

Available Online Services in EDC16C41 for Hexprog/Hextag users:

- Exhaust Gas Recirculation OFF

Check your online services from here to apply to one of these services: [My Online Services](#)



Pins Description

- Block1-Pin 36: Clock 1 Signal
- Block1-Pin 67: Clock 2 Signal
- Block2-Pin 16: K-Line Signal
- Block2-Pin 19: Power Supply 12-14V

- Block2-**Pin 2**: Ground
- Block2-**Pin 5**: Power Supply 12-14V