
Toyota EDC17CP37 Wiring

Connection using Factory Mode

Attention

You cannot use OBD Flash files to write into the ECU

You don't need to open EDC17CP37 cover in this factory mode. Please connect wires as described below



Pins Description

- Block 1-Pin 2: Ground
- Block 1-Pin 4: Power Supply 12-14V
- Block 1-Pin 59: Clock 2 Signal
- Block 1-Pin 61: Power Supply 12-14V
- Block 1-Pin 73: Clock 1 Signal
- Block 1-Pin 77: Power Supply 12-14V
- Block 1-Pin 80: CANBUS Low 2
- Block 1-Pin 81: CANBUS High 2