

## Seat DQ250 MQB Wiring

Connection using Factory Mode


### Attention

**You cannot use OBD Flash files to  
write into the ECU**



Seat-DQ250 MQB-Module

You don't need to open DQ250 MQB cover in this factory mode. Please connect wires as described below



### Pins Description

- Block1-Pin 10: CANBUS High 2
- Block1-Pin 11: Power Supply 12-14V
- Block1-Pin 13: Power Supply 12-14V
- Block1-Pin 15: CANBUS Low 2
- Block1-Pin 19: Ground