Benz EIZ W220-CH12

- Unplug EIZ from the car (Located under driver side trim panel for pedal mechanism. Careless Removal of the module may cause a damage to the car or the control itself, it must be carried under user's RISK)
- 2. Remove EIZ board from the casing



EIZ W220

3. Solder wires to EIZ based on the below connection diagram using BDM cable



EIZ W220 wiring

- 4.Select the EIZ /CPU version from HexProg software
- 5. Do the desired function for read/write EIZ in Software
- 6.Unsolder wires
- 7.Connect EIZ back to car

